



# PS 279 DUAL CHANNEL MASTER STATION



## USER MANUAL

August 2016

**This product is designed and manufactured by:**

ASL Intercom B.V.

Zonnebaan 42

3542 EG Utrecht

The Netherlands

Phone: +31 (0)30 2411901

Fax: + 31 (0)30 2667373

E-mail: [info@asl-inter.com](mailto:info@asl-inter.com)

Web: [www.asl-inter.com](http://www.asl-inter.com)

## CONTENT OF THIS USER MANUAL

1.0	SAFETY INSTRUCTIONS.....	3
2.0	GENERAL DESCRIPTION PS 279 .....	4
3.0	MAINS POWER.....	4
4.0	MECHANICAL INSTALLATION.....	5
5.0	FRONT PANEL CONTROLS AND CONNECTOR .....	5
6.0	REAR PANEL CONTROLS AND CONNECTORS .....	6
7.0	INTERNAL CONTROLS .....	7
8.0	TECHNICAL SPECIFICATIONS .....	7
9.0	PARTY LINE, TECHNICAL CONCEPT .....	8
10.0	CABLING.....	8
11.0	EARTHING CONCEPT .....	9
12.0	PS 279 BLOCK DIAGRAM.....	9
13.0	POSSIBLE SYSTEM CONFIGURATION .....	10

**Please always follow these instructions to help ensure against injury to yourself and/or damage to the system**

- 1) Read all safety and operating instructions before you operate the apparatus.
- 2) Retain all safety and operating instructions for future reference.
- 3) Heed all warnings on the apparatus and in the safety and operating instructions and follow all instructions for installation, operating and use.
- 4) Unplug the apparatus from the AC power outlet before cleaning. Use only a damp cloth for cleaning the exterior of the apparatus.
- 5) Do not use accessories or attachments not recommended by the manufacturer, as they may cause hazards and void the warranty.
- 6) Do not operate this apparatus in high humidity areas or expose it to water or moisture.
- 7) Do not place the apparatus on an unstable cart, stand, tripod, bracket or table. The apparatus may fall, causing serious personal injury and damage to the apparatus.
- 8) Do not block or cover any openings in the apparatus. These are provided for ventilation and protection from overheating. Never place the apparatus near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Do not place the apparatus in an enclosure such as a cabinet without proper ventilation.
- 9) Operate the apparatus using only the type of power source indicated on the marking label. Unplug the apparatus' power cord by gripping the power plug, not the cord.
- 10) Insert the plug properly. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized AC line plug has two blades with one wider than the other. This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug still fails to fit, contact an electrician to replace the obsolete outlet. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician to replace the obsolete outlet.
- 11) Route power supply cords so that they are not likely to be walked on or pinched by items placed upon or against them. Pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 12) Do not overload wall outlets or extension cords, as this can result in a risk of fire or electrical shock.
- 13) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14) Never insert objects of any kind into the apparatus through openings, as the objects may touch dangerous voltage points or short out parts. This could cause fire or electrical shock.
- 15) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

## 2.0 GENERAL DESCRIPTION PS 279

The PS 279 (19"/1RU) is designed to be a dual channel master unit in an ASL intercom system. Each channel has a Volume (listen level) control, a TALK and a CALL button with LED indicators and a side tone trimmer.

To connect the unit to its remote stations, use microphone cable with 2 wires and 1 shield

The built-in power supply can safely drive up to 20 Pro Series belt packs or 10 remote 2-ch speaker stations operating at full power. The power supply is protected against wiring mistakes (reverse power), short circuit or excessive thermal condition. Should one of these conditions occur, the unit shuts down. Once the fault condition has been removed, the unit resets automatically and full power is restored.

In case the number of user stations exceeds the capacity of the PS 279 power supply, the PS 285 booster power supply can be used.

Should the PS 279 be connected to another Intercom system, the 'System link' connector at the rear of the unit has to be used. This to avoid impedance problems.

Special attention has been paid to the intelligibility of speech. By applying low noise/high speed op-amps, a speech presence filter and a proprietary headphone amplifier, communication is very

comfortable even in environments with a high background noise level.

The unique CALL system provides both a flashing red LED and a very distinctive and characteristic sound signal. Only a short push of the CALL button will make the LED flash. The Call sound signal (buzzer) is activated by holding the button for two seconds. In case the sound signal is undesirable, all buzzers can be muted with the "All buzzers on/off" button.

Fully electronic switching allows for "soft" microphone on switching (latched or momentary) and remote Mic Mute facility. All microphones of stations connected to the PS 279 can be muted by pushing a single button on the front panel.

An AUX input at the rear panel allows inserting external audio signals at line level. The Aux signal can be routed to intercom line A and/or B, or directly to the local headset.

As an option, an XLR-6 headset connector can be fitted for binaural user of the headset cans (channel A + AUX signal on the left headset can and channel B + AUX signal on the right headset can).

Changing the position of internal jumpers makes it possible to route channel A + B to the left can and the AUX signal to the right can.

## 3.0 MAINS POWER & SAFETY EARTH

### **WARNING: This appliance must be earthed**

The PS 279 may be connected to a mains power outlet of 100 - 240 V AC (50 - 60 Hz), 100 watts. The outlet should have a clean earth. Avoid using mains power outlets which also power dimmer controlled lighting equipment.

The wires in the mains lead are color coded:

Green/yellow: safety ground

Blue: neutral Brown: live

In case the colors of the wires in the mains lead do not correspond with the colored markings of the terminals in your plug, proceed as follows:

- The wire that is colored green-and-yellow must be connected to the terminal in the plug, which is marked with the letter "E", or by the ground symbol, or is colored green.
- The wire that is colored blue must be connected to the terminal that is marked with the letter "N" or colored black.
- The wire that is colored brown must be connected to the terminal marked with the letter "L" or is colored red.

For personal safety and for proper functioning of the PS 279 and connected stations the green-and-yellow wire of the mains cord must always be connected to the electrical installation safety earth or ground. This wire is internally connected to all exposed metal surfaces. Any rack framework into which this unit might be mounted shall be connected to the same grounding circuit.

The PS 279 employs professionally designed input and output circuits which do not require the disconnection the safety earth to avoid hum loops.

Powering up procedure:

- Make sure the power switch is OFF.
- Connect the power cord to the unit
- Plug the other end of the power cord into a **PROPERLY GROUNDED** outlet.
- Turn on the power with the red button. The red overload LED will light up for about 3 seconds, then extinguishes and the green power LED will switch on, indicating the station is active.


## 4.0 MECHANICAL INSTALLATION

A vertical rack space of 1U (1.75" / 44,5 mm) is required for the PS 279. It is not necessary to provide rear support by extra bracing or shelving. Adequate ventilation must be provided by allowing sufficient space around the sides and rear of the unit to ensure free circulation of air.

Forced cooling is not required.

The power supply is mounted on the bottom of the PS 279. After a period of time it will feel hot to the touch on top and bottom. This is normal and should be no cause for alarm.

## 5.0 FRONT PANEL CONTROLS AND CONNECTOR



### 1 OVERLOAD LED

This red LED illuminates if the circuit breaker shuts off line power due to overload. A cause for overload can be too many user stations connected or a short circuit in the interconnecting cables. The circuit breaker resets automatically 3 seconds after the cause of the overload has been removed and restores the line power. During short circuit, the LED flashes every 3 seconds.

### 2 POWER LED

This green LED illuminates if line power is supplied by the built-in power supply.

### 3 SYSTEM LINK LED / CHANNEL A

This yellow LED illuminates if a channel of another ASL Intercom system has been connected to the PS 279 via the System Link connector (see #19) of the corresponding channel. The "other system" channel is now the MASTER channel and the "linked" PS 279 channel the SLAVE channel.

- The line impedance is now provided by the MASTER channel and line impedance of the SLAVE channel is switched off).
- One can talk, listen and call to and from all intercom stations on both the MASTER channel and the SLAVE channel
- A Mic Mute signal on the MASTER channel is received by the intercom stations on both the MASTER and the SLAVE channel. But a Mic Mute signal sent from the PS 279 is only received by the intercom stations on its own channels.
- A Buzzer Mute signal on the MASTER channel is received by the intercom stations on both the MASTER channel and the SLAVE channel. The Buzzer Mute button of the PS 279 is now disabled.

See #8 for "Mic Mute" and #9 for "Buzzer Mute".

### 4 SYSTEM LINK LED / CHANNEL B

Same as #3, but for channel B.

### 5 POWER ON/OFF switch

To switch the internal power supply ON and OFF.

### 6 BUZZER VOLUME trimmer

### 7 BUZZER

Indicates an incoming or outgoing call. It is activated by pushing a CALL button of the PS 279 or a CALL button on any other station on channel A or B for longer than two seconds, provided the buzzers are not muted (see #9). The buzzer volume may be adjusted with the buzzer volume control (see #6).

### 8 ALL MIC'S ON/OFF button

With this push button all microphones of the connected stations can be switched off. Each user station can activate its microphone again by pushing its TALK button.

### 9 ALL BUZZERS ON/OFF button

With this push button all buzzers of the connected user stations can be muted. The buzzers remain muted until the Mute button is switched off again.

### 10 AUX VOLUME controls


These knobs adjust the level of the Aux input signal to each of the two intercom lines.

### 11 A / B / HEADSET routing switches

These three push buttons route the Aux signal to either (1) Intercom channel A and/or Intercom channel B or (2) directly to the headsets.

### 12 VOLUME control knobs

To adjust the listen level of the headset, for each channel separately



**13 SIDE TONE trimmers**

To adjust the level of one's own voice as heard in one's headset. Adjustment procedure:

- set the trimmer in start position: fully clockwise
- switch off the microphone of all connected (speaker) stations
- switch on the microphone of the required channel
- turn up the volume of the required channel
- speak into the headset microphone
- adjust the listen level by turning the side tone trimmer

The operating area is between fully clockwise and minimum level. Adjusting the side tone does not affect the level of your voice as it is heard by other user stations.

**14 TALK buttons A & B**

These buttons allow talking to each channel separately or both channels simultaneously. If a Talk button is activated, its green LED is lit.

*Latched switching:*

If a TALK button is pushed shortly it is electronically latched and the microphone signal is sent to the referring channel. If the button is pushed again, the connection between microphone and the channel is cut off.

*Momentary switching:*

If a TALK button pushed and held, the microphone signal is sent to the referring channel until the button is released.

**15 CALL buttons A & B**

To activate the CALL system. A momentary push sends a visual Call signal to all stations connected to the referring intercom channel and the Call LEDs start flashing. If holding the buttons pushed for 2 seconds, the buzzers are activated. After the CALL button is released the LEDs continue to flash for a further 2 seconds.

**16 MIC GAIN trimmer**

To adjust the gain of the microphone signal

**17 HEADSET connector (XLR-4)**

To connect the headset to the PS 279. The headset can must have a minimum impedance of 200 ohms. In case of two cans in parallel, each can must have a minimum impedance of 400 ohms. The headset mic may be of the dynamic or electret type.


Pin assignments:

- Pin1: shield mic. (GND)
- Pin 2: mic. +
- Pin 3: phones +
- Pin 4: phones -

In case of 2 headset cans the wiring is such that both cans receive the same signal. The two headphone amplifiers run in a bridged mode.

As an option, an XLR-6 type connector can be fitted to allow a binaural headset configuration where a different signal will appear on each can. (See also section 7). In this mode the internal headphone amplifiers are not bridged.

**6.0 REAR PANEL CONTROLS AND CONNECTORS**



**18 DC INPUT connectors**

These connectors accept 24 – 30 V DC as a (backup) power source should mains power not be available or fail.

**19 SYSTEM LINK IN connectors (XLR-3)**

Input for the cable of an external party-line Intercom system. If a channel of the PS 279 is to be connected to another intercom system this connector accepts the communication signals from the other system. See also #4 and #5.

## 20 A & B LINE connectors (XLR-3)

To connect the PS 279 to remote stations via the intercom party lines. There are 2 connectors for each channel. Pin assignment: Pin 1: 0V / ground shield Pin 2: +30V power. Pin 3: audio wire

## 21 GROUND LIFT switch

If in "lift" position pin 1 of the AUX input XLR is lifted from ground.

## 22 AUX INPUT connector (XLR-3)

Electronically balanced input for line level audio signals. Pin assignment: Pin1: 0 V / ground  
Pin 2: signal (+), Pin 3: signal (-)

## 23 MAINS INLET


IEC Mains connector

## 24 FUSE

This fuse protects the PS 279 against severe internal damage in case of malfunction in the power section. Spare fuses are supplied with the unit.

**Before replacing the fuse the mains cord must be removed. Make sure that the correct fuse (T 1250) is placed in the holder.**

## 7.0 INTERNAL CONTROLS



**P 17** Setting A: Monaural (PCB with XLR-4 = factory setting)  
Setting B: Binaural (PCB with XLR-5)

**P 13** (in case of binaural setting only, see P 17)  
Setting A: left headset can: Ch A + AUX  
right headset can: Ch B + AUX  
Setting B: left headset can: Ch A + Ch B  
right headset can: AUX

**P 33** Jumper placed: Signal ground connected to Protective Earth (factory setting)  
Jumper removed: Signal ground disconnected from Protective Earth.  
This to avoid earth loop (causing hum) in case the PS 279 is connected to another party line intercom system via a System Link connector

## 8.0 TECHNICAL SPECIFICATIONS

### System

Dynamic range: 80 dB  
Frequency response: 200 Hz – 15 kHz (-3 dB)  
Call send signal: +2.8 mA  
Call receive signal threshold: +2.4V DC  
Operation voltage: 24 - 32 V DC  
Power interrupt time (mic mute): 0.1 sec.  
Line Impedance: 350  $\Omega$  (1 kHz) / 2.2 k $\Omega$  (DC)  
Audio level: nom.-18 dBu, max. 0 dBu

### Switch Mode Power Supply

Mains voltage: 100 - 240V AC, 50/60Hz  
Output voltage: +30V DC (+/- 5%)  
Max. output power: 75 Watts  
Circuit breaker delay time: 0.2 sec.  
Automatic reset time: 3.0 sec.

**DC Input** Supply voltage: 24 – 30 V DC

### Mic. Pre-amp

Gain: max. 40 dB  
Presence filter: +6 dB at 5 kHz  
Power to electret mic.: +9 V DC

### Headphone Driver Amps

Max. output level:  
monaural: 16 Vrms (@ 200  $\Omega$ )  
binaural: 2 x 10.3 Vrms (@ 400  $\Omega$ )  
Max. output power:  
monaural: 1.3 Wrms (@ 200  $\Omega$ )  
binaural: 2 x 0.27 Wrms (@ 400  $\Omega$ )

**Side Tone** Rejection: 0 - 30 dB adjustable

**Buzzer:** Max. SPL: 85 dBA

### Aux input (Line level)

Input impedance: 33 k $\Omega$   
Nominal input level: 0 dBu  
Max. input level: +22 dBu

### Dimensions & Weight

Width: 19" (483 mm) / Height: 1RU (44,5 mm)  
Depth: 150 mm / Weight: 1.85 kg

*0 dBu defined as 775 mV into open circuit  
ASL reserves the right to alter specifications  
without prior notice*

## 9.0 PARTY LINE, TECHNICAL CONCEPT

User stations in an ASL intercom system are connected via one or several 'party lines'. A party line offers two way ('full duplex') communication and consists of standard microphone (multi-pair) cable. One wire is used as an audio line, one as a power line and the screen of the cable functions as earth/return. Current drive is used for signal transfer. Each station utilizes a current amplifier to amplify the microphone signal and place it on the common audio line where, due to the constant line impedance (situated in the power supply between XLR pin 3 and 1), a signal voltage is developed which can be further amplified and sent to the headphones or loudspeakers.

This principle has three advantages:

- the use of a single audio line allows several stations to talk and listen simultaneously
- due to the high bridging impedance offered by each station, the number of stations on the party line has no influence on the level of the communications signal
- power and audio to the intercom stations use the same cable

The Call signal is also sent as a current on the audio line. It develops a DC potential over the line impedance which will be sensed by each station and interpreted as a Call signal.

## 10.0 CABLING

The intercom lines (the 'party lines') are of the shielded two-conductor microphone cable type. The intercom line connectors are of the XLR-3 type. Audio and Call signals are on XLR pin 3, DC power is on XLR pin 2. XLR pin 1 is connected to the shield of the cable which functions as the common return for audio and power.

The audio signal is transferred in an unbalanced way (see 'Party Line, Technical Concept').

To avoid earth loops (hum), the possible effect of electromagnetic fields and to minimize power loss, certain rules have to be obeyed when installing the cabling of an intercom system :

### **Use high quality cable**

Use high quality microphone cable (shielded two conductor cable, minimum 2x 0.30 mm<sup>2</sup>). In case multi-pair microphone cable is used, it should be of high quality and each pair should consist of two conductors (minimum 2x 0.15 mm<sup>2</sup>) with separate shield and an overall shield.

### **Use flexible cable**

Use flexible single and multi-pair microphone cable instead of cable with solid cores, especially when the cable is subjected to bending during operation or installation.

### **Cable screens to XLR pin 1**

The screen of each separate microphone cable and/or the screen of each single pair in a multi-pair cable, should be connected to pin 1 of each XLR-3 connector. Do not connect these screens to the metal housing of ASL unitst or XLR-3 wall boxes. See section 'Earthing Concept'.

### **Connect metal cable trunks, wall boxes and overall multi-pair cable screens to clean earth**

Metal cable trunks, metal wall boxes and overall multi-pair cable screens should be interconnected and, at the 'central earth point' in the intercom network only, be connected to a clean earth or a safety earth. See section 'Earthing Concept'.

### **Keep metal connection boxes and cable trunks or pipes isolated from other metal parts**

Metal trunks or pipes for intercom cables and metal connection boxes should be mounted in such a way that they are isolated from any other metal housing or construction part.

### **Keep cables parallel as much as possible**

When two (multi channel) units in a network are connected by more than one cable, make sure that these cables are parallel to each other over the whole distance between those units. When using multi-pair cable, parallelism is ensured in the best possible way.

### **Avoid closed loops**

Always avoid that intercom cables are making a closed loop. So-called 'ring intercom' should not physically be cabled as a ring..

### **Keep cables away from electromagnetic sources**

Keep intercom cables away from high energy cables, e.g. 115/230/400V mains power or dimmer controlled feeds for spotlights. Intercom cables should cross high energy cables at an angle of 90° only. Intercom cables should never be in the same trunks as energy cables.


### **Place power supply in a central position**

In case of a system powered by a separate power supply: In order to diminish power losses, place the power supply as close as possible to where most power consumption occurs, in other words most user stations are placed.


### **ASL powered units to a 'clean' mains outlet**

Master stations or power supplies should be connected to a mains outlet with a clean earth. Other audio equipment may be connected to this mains outlet, but avoid using an outlet which also powers dimmer controlled lighting systems.

# 11.0 EARTHING CONCEPT



# 12.0 PS 279 BLOCK DIAGRAM



## 13.0 POSSIBLE SYSTEM CONFIGURATION

